


## IC CARD INSERTION




Insert IC Card with the IC Chip face down.




**NOTE**

**IC Card is used for format modification and memory download purpose.**




## IC CARD OPERATION(ICC VIEW)


To view IC Card Contents ( DL/ID formats or stored data )



Insert the IC Card to access information contained on that card for upgrade purposes or memory view.




Insert IC Card to retrieve and view Stored data from the memory card.




Move the cursor to ICC VIEW and press ENTER to view information contained on the card.

Memory count display for 2 seconds.




Select ICC VIEW and press ENTER.



To view stored data, use the up and down


  arrow buttons.

Press ESC button to return to the main menu.




## IC CARD OPERATION(ICC UPLOAD TO S.W.)

To view IC Card Contents ( DL/ID formats or stored data )




Insert the IC Card to access information contained on that card for upgrade purposes or memory view.


Insert IC Card to retrieve and view Stored data from the memory card.



Move the cursor to ICC VIEW and press ENTER to view information contained on the card.




Memory count display for 2 seconds.




Select ICC VIEW and press ENTER.

**Connect the serial cable to your PC and run the PC software first before press ENTER.**




## IC CARD OPERATION(LOAD FROM ICC)


To upload DL/ID format upgrade and saved data.




To upload data from the IC CARD, insert the preprogrammed IC CARD  
(Do Not Format IC Card)




Move the cursor to LOAD FROM ICC and press ENTER button to continue.




Memory count display for 2 seconds.



Select OK and press ENTER to begin loading DL/ID formats or stored data from IC card.




When loading is complete, remove the IC Card from the slot to return to the initial display(Time&Date).




## IC CARD OPERATION(SAVE TO ICC)

Download stored data to the IC Card




Insert a formatted IC CARD.


See Formatting Instructions on page 24.



Move the cursor to **SAVE TO ICC** and press **ENTER** to continue.




Memory count display for 2 seconds.



Select the block of data that want to do save to ICC card.

Note : IC Card must be formatted before **SAVE TO ICC** function can be performed.



Select **OK** and press **ENTER** to save and confirm.


Remove the IC Card from the slot to return to the initial display(Time&Date).



## IC CARD OPERATION(ICC FORMAT)


### Memory Download Card

Format IC Card for Memory Card.




Insert a blank IC CARD.


See Formatting Instructions on page 20.



Move the cursor to ICC FORMAT and press ENTER.



Memory count display for 2 seconds.



Select OK and press ENTER to confirm.

Remove the IC Card from the slot to return to the initial display(Time&Date)



#### NOTE

**Formatting IC Card ensures card is blank and ready to receive download of data.**